



Rev. # 1-04

## PART # HS3097-4 1997-2003 FORD F150 REAR HANGERS & SHACKLES INSTALLATION INSTRUCTIONS

Please take the time to read these INSTALLATION INSTRUCTIONS and check the Hardware Parts List to be sure you have all the listed parts before beginning installation.

DJM parts should be installed by qualified mechanics. If you are not familiar with automotive repair have the parts installed by someone with experience.

Please read the warranty information (blue page enclosed). Complete your Product Warranty Card and mail it to DJM Suspension.

Please take a few minutes to fill out your installation helper (back side of warranty). Accurate measurements BEFORE BEGINNING INSTALLATION will show any irregularities in your vehicle.


NEVER WORK UNDER TRUCK SUPPORTED BY A JACK ONLY !!! USE QUALITY JACK STANDS WHICH HAVE A RATING ADEQUATE FOR YOUR TRUCKS WEIGHT!!!

NEW REAR SHOCKS DJM PART #2015 ARE REQUIRED.

## Hardware Parts List:


- 2- Spring Eye Hangers.
- 2- Shackles w/ bushings.(1012)
- 8- 7/16" x 14 Nylock Nuts.
- 8- 7/16" x 14 x 1-1/4" Bolts. 16- 7/16" Flat Washers.
- 2- 4 Degree Pinion Shim Kit.

Mount your new DJM Spring hanger in original holes on the frame with hardware provided, with offset towards the rear. The gas tank may need to be moved to gain access to bolts on driver side. Raise the axle so the front of the springs can be located in new hanger. With factory bolts, attach spring to hanger and install nuts. Do not tighten nuts. (Some may



find it easier to attach the spring to the hanger before bolting the hanger to the frame.) See fig #1 for typical hanger installation.

Apply some grease to the bushings and inside sleeves then attach new shackle on the frame mount and bolt in place with factory bolts (Fig #2). Shackle will install with bushings down and open side forward. The hole farthest away from bushing will lower truck more than the closer hole. Now raise the rear axle high enough to align the spring eye and shackle. Insert the remaining bolt and install nuts.



Install rear wheels and torque lug nuts. Remove jack stand and floor jack. Check the height of the rear. You can change the height by moving the spring to the other hole in shackle. When satisfied with the height, install new shocks. Tighten all bolts.

Take truck for test drive.

If drive line vibration occurs install pinion shims. Install new leaf center pin with spacer between bolt and spring. Tighten nut and cut off any excess bolt. The shim is used to tilt the front of the axle down to line up drive shaft. Install with the thick end forward.



Record complete height on installation helper. Double check all hardware.

## Caution : Leaf springs are under considerable tension. Good judgment should be used when removing shackle bolts. The rear spring may move causing a pinch point between the spring and rear shackle.

Loosen and remove the two shackle bolts, and remove the stock shackle.Tests fit the shackle, align bushings with frame holes and insert bolt. Check to see if shackle will move freely to rear without hitting the bottom of the bed or any braces attached to bottom of bed.

Remove the bolt holding front of the leaf spring to the front spring hanger. Remove the rivets holding spring hanger to the frame. This can be done with a air chisel, grinder or drill out rivets.