



ASB2001R

INSTALLATION INSTRUCTIONS Tahoe Suburban Yukon 2wd

NOTE: Products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components. Please read instructions from start to finish and verify the parts in the parts list before beginning installation.

Rear Parts List

<u>Item</u>	<u>Quantity</u>
Rear anti-sway bar	1
Bushings	2
Lube	1

1. Park vehicle on a smooth, level, asphalt or concrete surface. Block front wheels. Jack up rear end of the vehicle and support frame with jack stands.
2. Locate and remove the nuts that attach the ends of the OEM anti-sway bar to the end links. Remove the bolts that attach the bar mounting brackets to the rear end housing, and remove the OEM anti-sway bar from the vehicle.
3. Liberally grease the inner bore of the new polyurethane bushings with lubricant provided, place the bushings over the new anti-sway bar in the same locations as the OE configuration. Install the rear anti-sway bar using factory hardware and brackets. Torque mounting bolts to 30-34 ft.-lbs
4. Attach end links to the new bar. Torque end links to 38-40 ft/lbs.

5. Lower rear of truck onto ground, and roll back and forth to settle suspension.
6. Installation is complete. Check assembly periodically for grease and tightness.

**DJM Suspension 580 West 184th Street,
Gardena CA, 90248
800-237-6748
www.djmsuspension.com**