



www.djmsuspension.com

PART # CA2599UN (K6540)
1999 – 2006 Chevy Silverado / Sierra

CA2000U (K6540)
2000-2006 Tahoe/Yukon, Silverado/Sierra, Suburban/Yukon XL

CA2507UN (K6540)
2007-2015 Chevy Silverado/Tahoe / Avalanche / Suburban

UPPER CONTROL ARMS INSTALLATION



Install the grease fitting on the TWIN TUBE SLEEVES. Make sure to pregrease the sleeves to make sure the predrilled holes are free and the grease flows smoothly. If the ball joint is greaseable grease it at this time if it is maintenance free (no grease fitting) no action is necessary. Now install and align the arms to factory specifications.

www.djmsuspension.com
580 West 184th Street Gardena Ca 90248

contact us:

tech@djmsuspension.com

orders@djmsuspension.com

310-538-1583