



# CA2515-3 AND CA2515-4 2016-2018 Silverado 2 Wheel Drive Only



Install the grease fitting on the TWIN TUBE SLEEVES. Make sure to pregrease the sleeves to make sure the predrilled holes are free and the grease flows smoothly. If the ball joint is greaseable, grease it at this time. If it is maintenance free (no grease fitting) no action is necessary. Now install and align the arms to factory specifications



SCAN HERE FOR MORE INFO



On 2016-2018 steel knuckle only. There is a small burr on the upper ball joint taper. This can be removed with a file or a die grinder. Test fit the upper ball joint to make sure there is no interference.



**www.djmsuspension.com**  
**580 West 184th Street Gardena Ca 90248**  
**contact us:**